



Operation manual

Model	BD43 5-section recordable circuit
 <p>Connection: When connecting the recording and playback tool to the module, please make sure all components are facing up and speaker on the tool is connected to the left side.</p>	<p>Switches: Red: Record switch White: Play / record sections Blue: erase switch.</p> 
<p>Features</p>	<ul style="list-style-type: none"> ● Record up to 300 seconds ● 5-section recording
<p>Operation</p>	<p>Recording:</p> <ol style="list-style-type: none"> 1. PRESS & HOLD RED switch then PRESS & HOLD one of the WHITE switches. The LED indicator lights up to start recording. 2. Speak into the microphone at a 3–5 cm distance with normal speaking volume. 3. Release both switches to end recording. <p>Note: The module can record up to a total of 300 seconds. User can distribute the 300 seconds as various duration lengths to each of the 5 segments. If the memory is full, the user needs to erase the recording before it can be recorded again.</p> <p>Playing:</p> <ol style="list-style-type: none"> 1. Press the white switch to play the recording. Each white switch represents one section of recording. <p>Erase:</p> <ol style="list-style-type: none"> 1. Press the blue switch to clear the memory. <p>Note: All recordings in all sections will be erased.</p>